



Woodturning Made Easier With Innovative Products

Thank you for your order!

All Rubber Chuckies are trued and/or tested before shipping. Due to user preference and/or lathe configuration i.e. .spindle length, scroll chuck configuration, etc. which affects runout it may be necessary to re-true your Rubber Chucky.

To true up your product, we suggest to gently place the shank of a chisel on the surface of the applicable Rubber Chucky while it is turning - if it bounces then it needs to be trued up.

If this is the case; we suggest making a very slight shear cut to the surface. We use a gouge or square carbide tool; but feel free to use the tool with which you are most familiar. Then repeat the aforementioned process of placing the chisel shank on the surface - if it doesn't bounce then it is trued up. **Be careful with this procedure; if you don't understand it please contact us for further instructions BEFORE proceeding.**

“Truing it up” slightly roughens the surface; allowing for better gripping of the workpiece. This enables you to put less pressure on your workpiece, eliminating the burning of the wood and possible breakage of the workpiece which can occur with a (wood jamb chuck) wood on wood surface from over-tightening.

Please remember that if you have any questions concerning the use of your Rubber Chucky product to please either email us sales@rubberchucky.com or call us at 248.877.0828.

The safe use of any Rubber Chucky product is entirely the responsibility of the purchaser/user. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of any Rubber Chucky Products, LLC product will constitute your agreement to your responsibility.

WWW.RUBBERCHUCKY.COM