

# Bullet Chucky Instructions



The Bullet Chucky is used to hold any size opening (from 3/4" up to 1 3/4") in a workpiece between centers.



**Mounted in Scroll Chuck and Live Center**

The taper allows it to adjust to the odd size hole as we know that all of the holes we put in a workpiece are not exactly the same.



**Hollow Form mounted on Chucky Arbor and Live Center**



**Bird House Ornament with a Bullet Chucky and Drive Chucky for refinishing.**



**Holding a Candle Holder between centers.**

**The Bullet Chuckies can also be reshaped to whatever size you may need. You can even square off the end or make it end concave to accommodate your workpiece.**

**If reshaping the Chucky, be sure to take very light cuts with your chisel.**

**To increase the gripping power of the Bullet Chuckies, lightly sand the surface to “roughen” it up. Just touch it a little bit – too much sanding will make it smooth again.**

**The safe use of this product is entirely the responsibility of the purchaser. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of this product will constitute your agreement to your responsibility.**

**[www.rubberchucky.com](http://www.rubberchucky.com)**  
**[sales@rubberchucky.com](mailto:sales@rubberchucky.com)**  
**248.877.0828**