

Attention

Locating a thread on a thread (nut in Chucky to threaded arbor or Live Center) can cause some wobble or run-out due to the positioning of the threads in relation to each other.

This condition can be improved by re-positioning the 3/4-10 nut and the Chucky on the arbor.

Thread the nut all the way onto the arbor.

Thread the Chucky onto the arbor.

Bring the nut up to the Chucky and check for run-out.

If there is a wobble simply change the depth of the arbor in the Chucky and adjust the nut accordingly. This may take several tries of adjusting a half to full thread one direction or the other.

Be sure to always use the nut on the arbor and bring it up to the Chucky as this also prevents the Chucky from running too far onto the arbor and causing it to lock onto it or damaging the Chucky.

This procedure can also be used if mounting the Chucky on your Live Center.

If you have any questions please do not hesitate to contact us.

The safe use of this product is entirely the responsibility of the purchaser. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of this product will constitute your agreement to your responsibility.

WWW.RUBBERCHUCKY.COM

248-877-0828

sales@rubberchucky.com