

## **Drive Chucky Instructions**

**The Drive Chuckies are meant to be mounted on the Live Center (with removable cone) when you remove the 60 degree cone.**

**Simply thread the Drive Chucky onto the threaded shaft.**

**They can also be mounted in the headstock with our Optional MT2 Chucky Arbor (sold separately)**

**You can reshape the Drive Chuckies by removing small amounts of material per cut. Use the chisel of your choice for doing this. There is approximately 3/16” of material on the end of the Drive Chucky; so be careful with how much you remove.**

**Please remember that if you have any questions concerning the use of your Rubber Chucky product to please either email us [sales@rubberchucky.com](mailto:sales@rubberchucky.com) or call us at 248.877.0828.**

**The safe use of any Rubber Chucky product is entirely the responsibility of the purchaser/user. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of any Rubber Chucky Products, LLC product will constitute your agreement to your responsibility.**

**WWW.RUBBERCHUCKY.COM**