

# Platter and More Vacuum Chucky Instructions

Although the Platter and More Vacuum Chucky was originally developed for vacuum chucking Platters; it can be used for any appropriate workpiece.

**If used in the Headstock (for jam chucking or vacuum chucking) the Platter and More Vacuum Chucky requires either a Chucky Arbor or a Chucky Vacuum Arbor.**

To use on the Tailstock it requires a Live Center that has an exposed 3/4-10 threaded shaft.

If you already have a Chucky Arbor or Chucky Vacuum Arbor they will work with this product.

Although it was designed for (and we recommend) use as a Vacuum Chuck it can be used as a jam chuck or a vacuum chuck. It cannot be used in a Scroll Chuck because there is no tenon.

For vacuum chucking you will also need a vacuum supply. We offer a “plug in” vacuum adapter that fits several lathes. See details on the website

[https://www.rubberchucky.com/store/p150/Vacuum\\_Adapters.html#/](https://www.rubberchucky.com/store/p150/Vacuum_Adapters.html#/)

**The Lamp Rod or Hose Style Vacuum set up will not work.**

We also recommend our **Chucky Alignment Adapter** to aid in aligning your workpiece to the Vacuum Platter Chucky

[https://www.rubberchucky.com/store/p104/Chucky\\_Alignment\\_Adapter.html#/](https://www.rubberchucky.com/store/p104/Chucky_Alignment_Adapter.html#/)

Remember to always take light cuts when holding a workpiece with any vacuum chuck.

These and all Rubber Chucky instructions and links are also available on the website under **Product Instructions**

**The safe use of this product is entirely the responsibility of the purchaser. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of this product will constitute your agreement to your responsibility.**

**[WWW.RUBBERCHUCKY.COM](http://WWW.RUBBERCHUCKY.COM)**

**248-877-0828**

**[sales@rubberchucky.com](mailto:sales@rubberchucky.com)**