

Vacuum Seals for HoldFast Vacuum Chuck

NOTE: We recommend that vacuum chucking only be used for light finish cuts and/or sanding. If using your vacuum chuck for removing the tenon ensure that you take small cuts as trying to remove too much material at once can result in dislodging your workpiece.

Remove the “O” Rings from the HoldFast Chuck. Clean the surface, removing any glue left from the “O” Rings.

The new design of the seals enable the “lip” on the back of the seal to go over the chuck. The 6” seal is relatively easy to slip over but you may need to use something like a screwdriver or popsicle stick to aid in doing this. Kind of like putting a tire on a rim.

If you find it too difficult to install in this manner, simply trim the “lip” off with a pair of scissors. The seal will work fine this way.

The “lip” on the 3” seal has been removed as it is too difficult to install like the 6” seal.

It is not necessary to glue the seals onto the coupling – simply slip them on.

The safe use of any Rubber Chucky product is entirely the responsibility of the purchaser/user. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of any Rubber Chucky Products, LLC product will constitute your agreement to your responsibility.

WWW.RUBBERCHUCKY.COM