

## Spatula Chucky Instructions

### **SPECIAL NOTE**

**Do not over tighten with your Live Center. The slot in the Spatula Chucky is only there to hold the spatula between centers - it doesn't have to be tight. Too much pressure from the Live Center will crack the Spatula Chucky and void the warranty.**

The Spatula Chucky can be mounted on your lathe in three different ways (shown below).



On a Live Center with Removable Cone



On our Optional Chucky Arbor



In your Scroll Chuck with jaws that close to at least 1 ½ inches.

If you wish to remove and remount the Spatula, simply draw reference lines on the face of the Spatula Chucky and workpiece with a pencil to aid in remounting the workpiece. When finished erase the reference lines.

**The safe use of any Rubber Chucky product is entirely the responsibility of the purchaser/user. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of any Rubber Chucky Products, LLC product will constitute your agreement to your responsibility.**

**WWW.RUBBERCHUCKY.COM**

[sales@rubberchucky.com](mailto:sales@rubberchucky.com)

248-877-0828