

Vacuum Seals for PVC Couplings

NOTE: We recommend that vacuum chucking only be used for light finish cuts and/or sanding. If using your vacuum chuck for removing the tenon ensure that you take small cuts as trying to remove too much material at once can result in dislodging your workpiece. When possible always use your tailstock with a live center along with the vacuum chuck.

These seals are not meant to be used on PVC Pipe. They are to be used on Schedule 40 Couplings of the appropriate size.

We strongly recommend using Genova PVC Couplings available on our website or at most True Value Hardware stores. We recommend these because we have found that they have the most consistent wall thickness and concentricity.

It is not necessary to glue the seals onto the coupling – simply slip them on.

If the seal is a little loose, you can adjust the wall thickness of the coupling by wrapping it with masking tape to enlarge its outside diameter. Usually two or three wraps of one inch wide masking tape works well but more or less may be required.

The safe use of any Rubber Chucky product is entirely the responsibility of the purchaser/user. If you do not agree with this, please return the Rubber Chucky product immediately for a full refund. Your use of any Rubber Chucky Products, LLC product will constitute your agreement +to your responsibility.

WWW.RUBBERCHUCKY.COM